

ShowerStick – Shower Water Softener – from WaterSticks - Installation Instructions

*****NOTE: THESE INSTRUCTIONS ARE FOR SHOWERSTICKS PURCHASED PRIOR TO 12/9/24 -OR- SHOWERSTICKS INSTALLED WITHOUT THE HANGER**

-*Want an easy and flawless installation? Watch our Installation Video while installing your ShowerStick!! See “Videos” at the top of our website.

-You don't need a plumber or maintenance person to install the ShowerStick. YOU are much more likely to follow the instructions (we hope) so there are no issues. **PLEASE follow these instructions carefully!!!** We want you to have a great experience with the ShowerStick!

1. Remove the red plastic plugs

Remove these from each end of the ShowerStick. Save them so if you ever move or store your ShowerStick for a prolonged period, you can re-insert them to keep air from getting inside to dry out and kill the resin inside the ShowerStick. (See Storage instructions below.)

2. Remove Old Shower Head

Unscrew by hand counterclockwise or with a tool if needed (add a rag under the tool to protect the finish). Remove old plumber's tape from pipe (wire brush may be needed) then wipe clean with rag. Inspect the pipe's male threads to be sure they aren't damaged from previously used tools. This is important to ensure the ShowerStick assembly gets a good secure connection. Add new plumber's tape (included) to the pipe's threads clockwise 3-4x around to prevent leakage.

3. Attach the Shower Arm Mount (“Mount”) to the pipe

The mount comes with a white angle connector (22-1/2° elbow) attached below it. Unscrew the plastic cap on the mount and ensure the black washer is pushed up inside the end of the mount and is lying flat. To adjust the angle, loosen the center joint just a little (don't unscrew all the way). Be sure the mount's center joint is tightened, then attach the mount to your pipe **BY HAND (no tools!) AND JUST SNUG – OVERTIGHTENING WILL FRACTURE THE FITTING.**

*Note: If you purchased the optional KDF Filter, please see page 2.

4. Attach the ShowerStick Body

Be sure the plumber's tape is still wrapped around the top fitting of the ShowerStick body then add the body to the assembly **JUST SNUG – DON'T OVERTIGHTEN** (it won't screw all the way up the threads).

Try to face the regeneration port to the front or side, but not the back.

5. Attach the Shower Hose

Unscrew the plastic caps from each end of the hose. While holding the ShowerStick body steady, attach the end of the hose with the nut (not the cap) to the bottom of the ShowerStick body – hand tighten only and just snug (it won't screw all the way up the threads). Point the other end towards the drain, turn on the water and let it run for 1 minute to rinse out any residual 'color throw' on the resin from the manufacturing process.

6. Attach the Shower Head

Attach the head to the hose (the end with the cap, not the nut) then place the head in the mount. Now you can take a soft water shower whenever you'd like.



No need to regenerate yet, it's good to go!

Storage: Keep full of water, keep regeneration port cap attached and insert provided red plastic plugs in each end so air won't get inside to dry out and kill the resin. See our website's FAQs page for detailed instructions.

Backwashing: This should be done yearly (or 2-3 times a year if you have well water or city water with noticeable iron) to loosen up and clean out the resin bed for better regeneration and to help ensure the resin has a long lifespan. Instructions can be found on our website's FAQ page.

Parts & Accessories: All parts in the ShowerStick assembly are available on our website's Store page.

***Reviews:** To post a Review, please visit the “Reviews” tab at the top of our website.



Regeneration Instructions

When to Regenerate:

You don't need to regenerate your ShowerStick after installation. After installed, the test strips will show you now have soft water (zero grains). As you use the water, the grains will start to increase. 0-3 grains = soft water, so you should regenerate to keep the water in this zone. (Moderately hard = 3-7 grains, hard = 7-10, very hard = 10-14, extremely hard = 14+) Follow the instructions on the test strips package.

How to Regenerate:

1. Remove the regeneration port cap and gently place the shower head/hose on your shower floor to allow the water to drain.
2. Using an empty 1-liter water or soda bottle, pour 1 cup of plain or iodized table salt (Morton's or any store brand) into the bottle and fill with tap water. Shake well until the salt is dissolved.
 - a) Don't use coarse grain salts (softening salt pellets, rock salt, sea salt, kosher salt) since they won't dissolve as well in water and therefore won't thoroughly regenerate the resin.
 - b) Warm or hot tap water works faster (not better) to dissolve the salt. Boiling water should never be used.
 - c) Draw a line with a Sharpie to show where the one cup of salt came up to on the bottle, so you don't have to measure the salt again in the future and can just pour it inside to the line.
 - d) It's important to use this size bottle with this amount of salt because you need to overwhelm the resin with a certain concentration of saltwater to do the best possible job to regenerate the resin.
3. With the shower head still on the floor, slowly pour the saltwater into the regeneration port. If it backs up while pouring it inside, give it a few seconds to drain out. If salt is left at the bottom of the bottle undissolved, add a little more tap water to the bottle, shake, then pour inside. The more the salt is dissolved, the better job it will do to regenerate the resin.
4. After the saltwater flows out through the shower head and down the drain, place the shower head/hose back up in the mount and re-attach the regeneration port cap. (Tip: use your bath towel to tighten the last notch – this is helpful especially when the cap is wet)
5. Turn the water on to let it run for 10 seconds to fill the ShowerStick back up with water and to rinse the residual salt through to finish the regeneration process. You now have soft water again and can take a shower whenever you'd like.

Tip: Since soaps and shampoos lather better in soft water, you can now use about 50% less of them!

Optional Accessories

KDF Chlorine Filter

*For visual KDF filter installation instructions, please watch our video! <https://watersticks.com/video-library>

1. Be sure the black rubber o-ring is pushed up flat inside the female end.
2. Wrap plumber's tape clockwise 5-7x around the male threaded end to prevent leakage. **Don't skip this step!**
3. Attach the male threaded end (faces upward) onto the Angle Connector by hand (no tools) just snug. **DON'T OVERTIGHTEN or it will break.** The female end (with o-ring) attaches to the top of the ShowerStick. Remember to replace it yearly, otherwise it can become clogged and reduce your water pressure. (Tip: Set a reminder on your phone to pop up each year.) Continue with steps on page 1.

Flow Control Valve

Allows you to stop or reduce the flow of water while soaping, shampooing, or shaving to conserve your soft water and extend the interval between regenerations. Slide the button over to reduce the water pressure, then slide it back to resume to the original pressure and temperature. Install between the shower head and hose.